



Metal transport straps provided for all springs, these ensure the feeder does not move during transportation.
Metal transport straps **MUST BE REMOVED PRIOR TO OPERATION.**

Please note:
1) Drawing may be subject to changes without notification.